

DAKOTA SAFETY

Installation Instructions for Model A-SM1 FallGuard® Skylight Screens

Skylight can be brittle. Do Not Touch Dome, Pyramid, or Glazing. Wear Gloves when handling screen. Wear Safety Glasses when installing FallGuard® Rails.

1. Center FallGuard® Rail onto Length Side of Skylight Retaining Frame
2. Secure the FallGuard® Rail on to skylight retaining frame with specially provided galvanized steel hex washer self-drilling screws through the pre-punched holes.
3. Center the screen over the skylight and Install the Bases of the Screens into the Rail Notch openings.
4. Install the furnished stainless Steel Clips by snapping them in place on the rail notches. Start on the ends and space about ~12-18" apart (**One Bag Per FallGuard®!** **Clips don't need to be on all Notches.** # Clips/2 = 1 Rail.

Model A-SM1 FALLGUARD® Skylight Screen

Patent No.
5,237,788

